


ASM1062 F/W update to 06040000.ROM SOP

Note: Program tool have to run it on real DOS environment, not Windows DOS mode

1. Please unzip RE1062.A21.zip and copy RE1062.A21 folder to C:\
2. Boot into DOS
3. Please into C:\RE1062.A21
4. Type "ahci.bat" to start update firmware
5. When screen shown "PASS : 1 FAIL : 0" that's mean update finish and successful.



Check new Firmware version

Firmware Version: 200604_00_00_00

