



## 20250 USB 3.0 Card Reader Software Upgrade Instruction

1. Extract the compressed (.rar) file to the folder with the same name on a Windows computer.  
(It is recommended to copy the compressed file to desktop and then extract.)
2. You will see the following files in the folder as shown in the Picture 1.




(Picture 1)

3. Connect the Card Reader to an available USB port of your computer, open “MultiTool.exe” application in the “MultiTool 2.0.9.9” file, and then click on **F/W & EEPROM** option in the popup dialog box as shown in the Picture 2




(Picture 2)

4. Click “Load FW obj file”  
as shown in the Picture 3.




option in the popup window



(Picture 3)

Import “FW1533.bin” file as shown in the Picture 4: Desktop>>20250 USB 3.0 Card Reader Software Upgrade Instruction folder>>Software folder>>Select FW1533.bin file>>Open




(Picture 4)

5. Click “Write F/W”




option to start software upgrade.



(Picture 5)

6. The update has been completed successfully as shown in the Picture 6. Click “OK” and exit on the bottom right in the box.



(Picture 6)

7. Re-plug the Card Reader and now it is ready to work on your latest Windows 10 system.